

Import of the inkjet media library into sw Mirage

Thank you for the inkjet media library downloading. Its installation will expand the range of print media in sw Mirage. The library contains calibrated FOMEILAB media and provides you with a convenient photo printing with predictable and repeatable results.

Recommendations

- have professionally calibrated and profiled display
- keep your printer in perfect condition, verify the nozzle functionality (nozzle check)
- view the photos in daylight or under standardized light source (CRI ≥ 97)

Working with the media library

- from the downloaded zip archive extract the media library - *zmediapkg* file
- open sw Mirage
- in Settings (Preferences), in the Custom Media tab select on the left side down the Install Media button
- find the extracted media library (*zmediapkg* file) and touch the Open button
- confirm the successful installation of the media library

Now you can print!

Note: You have downloaded the inkjet media library containing generic ICC profiles. They were created with all the care by using a professional measuring equipment and profiling software, under recommended conditions (temperature 18-25 °C, humidity 40-60 %). To get a custom ICC profile based on your particular printer and Your specific environment, contact us at fototisk@fomei.com.

Convert image data to photography, print your snaps. Beyond your own joy from the fact „I can complete the photo process“, you will find that on the paper photos you can discover the context and mistakes that the display has concealed. By printing and evaluating your photos, you will become a better photographer. Good light!

